Smart Blinds mobile app instruction

GET IT ON Google Play

Download on the App Store

Search for: „smartblinds”.

Turn on Smart Blinds motor

Allow access to the device's location (this is necessary for the Bluetooth functionality to work properly).

Press to add a blinds.



Select the roller shutter from the list (if you have several motors, we recommend turning on the next motor after adding the previous roller blind to the application).



Press: **next step.**



Default password: **5555**



The settings screen will appear.



You can find settings in the upper right corner of the application.



Settings



1. The name of the blind
Give the roller **your** own name and **confirm**.



2. Type of blind
Choose roller blind picture that suits you and **save**.



3. Change the password
Change the password to your own and **confirm**.



4. Blind direction setting
It is possible to change the direction of blind:
to do this, press



5. Upper limit setting of the blind
Hold **Open** or **Close** until the blinds is fully open, press **Stop** and **Save**.



6. Bottom limit setting of the blind
Hold **Open** or **Close** until the blinds is closed completely, press **Stop** and **Save**.



7. Moving speed setting
The default is the fastest winding speed. To decrease it, press
For advanced users: enter the height of the roller blind and the diameter of the mechanism to adjust the winding time to your preferences.



8. Dot/Continuous setting
This setting determines whether or not each touch of **Open** and **Close** will cause the roller shutter to move, or it will be necessary to briefly hold it.



9. Winter / Summer mode
This setting is related to the light sensor in the solar panel *: if you don't have one, you don't have to do anything.

10. Timing settings allow you to set the opening or closing time of blind.
Press + to start



10. Timing settings
Set the position of the blind moving the button

Select the exact time and press duplicate to select days.



10. Timing settings
Select days and **confirm**.



10. Timing settings
To start the timer, press:



10. Timing settings
To edit or delete a timer hold your finger on its name longer.

10. Timing settings
You can set a maximum of 4 different timers.

To edit / delete, press and hold your finger longer on the timer.



11. Delete the blind

This setting is used to remove the blind from the app.



12. Clear all settings

You can delete all settings. This will restore the initial default settings.



Device control

The start screen of the application shows a list of all added blinds. Smart Blinds within bluetooth range will connect automatically after 2 to 3 seconds. Select the blind to control it.



Device control

You can control the roller shutter using buttons **Open** - **Stop** - **Close**, or by moving your finger on the drawing of the roller blind. This screen also shows the battery level of the Smart Blinds device.

Scene control

Smart Blinds devices can be combined into groups to perform planned scenarios, e.g. to open all blinds in a room with one button.
To add first scene press



Scene control

Press scene name to add your name of scene. Then press to add chosen blinds.
(note: to add a roller blind, it must have the "connected" status in the application).



Scene device position

Set the desired roller blinds target position and press **Confirm.**



Scene device list

After adding the chosen blinds, press **save scene.**

 **Scene control** Press the name of the selected group, and then the **start scene** button - the blind will move to the preset positions.	 **Scene control** Press and **hold** scene name to edit or delete a scene	 **Device control** Press device control to go back to start screen..	The manual applies to Smart Blinds version 1.0 (from 04/12/2020). In the future, there may be new versions of the application introducing additional possibilities and functions. Find information on this subject on the smartblinds.pl website or directly in the application store (Google Play or Apple APP Store).